

RayNeo X3 Pro XR Score Viewer Controls

Right-temple touchpad operator guide

All in-app gestures use the touchpad on the right temple of the glasses. A single tap changes visualization; a double tap changes sensor. These are different commands.

Start

1. Put on the RayNeo X3 Pro glasses.
2. Use the button on the underside of the right temple to power on the glasses.
3. Open the app launcher and navigate to XR Score Viewer.
4. Open the app.
5. After the AMPLIFY splash screen, wait while the app checks for Redis.
6. The first visualization appears in front of you. The sensor HUD shows the active sensor when live streams are available.

Cycle Through Visualizations

1. Single tap the right-temple touchpad once.
2. The app advances to the next visualization.
3. Single tap again to continue through the list. After the last view, the app returns to the first.

The current cycle is: score/image board → abstract particle mesh → objective five-channel graphs → ArtistViz placeholder → back to the score/image board.

Cycle Through Sensor Streams

1. Double tap the right-temple touchpad with one finger.
2. The app selects the next discovered sensor.
3. Check the sensor HUD. It displays SENSOR n / total and the active sensor identifier.
4. Double tap again to continue through the sensors. After the last sensor, selection returns to the first.

The active sensor drives the abstract mesh, the objective graphs, and the ArtistViz data path. If only one sensor is available, a double tap leaves the same sensor selected. If no streams are available, the HUD displays NO SENSOR STREAMS.

Make the Active Visualization Smaller or Larger

1. Look directly at the active visualization. Scaling is gaze-aware, so a swipe is ignored if your gaze does not intersect the visual.
2. Swipe forward on the right-temple touchpad to make it smaller.
3. Swipe backward to make it larger.
4. Repeat until the visual is comfortable to view. The app limits the minimum and maximum size.

Move the Active Visualization Up or Down

1. Swipe up on the right-temple touchpad to raise the active visualization.
2. Swipe down to lower it.
3. Repeat until the visual is at a comfortable height. The app limits vertical movement.

Quit the App

1. Tap the right-temple touchpad with two fingers at the same time.
2. The app closes.

Do not use a one-finger double tap to quit. In the current app, a one-finger double tap cycles to the next sensor.

Quick Reference

Action	Right-temple control	Notes
Next visualization	Single tap	Cycles through four configured views.
Next sensor	One-finger double tap	Check the sensor HUD for the selected ID.
Make smaller	Look at the visual, then swipe forward	Ignored when gaze misses the active visual.
Make larger	Look at the visual, then swipe backward	Ignored when gaze misses the active visual.
Move up	Swipe up	Moves the current active view.
Move down	Swipe down	Moves the current active view.
Quit	Two-finger tap	Two fingers together, not a double tap.